


1.5 IR BLUE BUTTON/LIMITED EDITION REMOTE



TV Mode Button

Press to control TV functions

SAT Mode Button

Press to control satellite receiver

TV/Video Button

Press to switch through TV Inputs

Menu Button

Press to view the Main Menu

Volume Button

Press to lower or raise the TV sound

Mute Button

Turns TV sound On/Off

Select/Play Button

Selects highlighted item on the TV Screen or Play in VCR mode

Left/Themes/Rewind Button

Moves cursor to the Left, views the Themes Menu when in Satellite Mode, and Rewind in VCR mode

Recall Button

Returns to previous channel

Info Button

Displays program information

Sys Info Button

Displays the satellite receiver System Information Screen

Star Button

*Press to backspace without deleting while using the Search feature

VCR Mode Button

Press to control VCR functions

Aux Mode Button

Press to control Stereo, DVD etc.

Power Button

Turn On/Off the selected mode

Page Up/Down Button

Use to Page Up or Down in the Program Guide or in the Themes List

Guide Button

Displays the Program Guide and cycles through the Favorite Lists

Up Button

Channels up, Moves the cursor up, and Stops in VCR mode

Right/Browse/Fast Forward Button

Move cursor to the Right, opens the Browse Banner when in Satellite Mode, and Fast Forward in VCR mode

Cancel Button

Cancels the screen currently displayed

Down Button

Channels down, Moves the cursor down, and Pause in VCR mode

View Button

View the Program Banner while watching programming

Record Button

Press to Record in VCR mode

Number Buttons

Used to enter channel numbers, navigating the Interactive Menus, and the letters in *Search Menu

Pound Button

*Used in SAT Mode to display the Search Screen